7CH model

Channel	Value	Function	
CH1	0-255	Zoom function	
CH2	0-255	Zoom speed from quickly to slowly	
CH3	0-255	Main dimming from dark to bright	
CH4	0-255	Control strobe from slowly to quickly	
CH5	0-255	Auto running choose	
CH6	0-255	Auto running speed from slowly to quickly	
CH7	0-10	No function	
	11-20	Linear 1	
	21-30	Linear 2	
	31-40	Linear 3	
	41-249	Linear 4	
	250-255	Reset	

Important notice:

- ♦ Before open the LED cob par light and if you want to do the repair work, please make sure the power source is at the separation condition.
- Unceasingly carries on the product improvement about our company the policy, in this instruction booklet carries the data will have the possibility to be able to change in the future, when no longer separate notice change matters concerned. Our company retains when the product improvement changes the related specification the authority. This instruction booklet publisher cannot be responsible regarding this instruction booklet in information accuracy, also cannot the related consequence which causes regarding these information be responsible.

MJ-3047A200-5700K



User Manual

_PROFESSIONAL STAGE LIGHTING ==

Thank you for choosing our LED cob par light. For the sake of your safety, Please read and follow these instructions carefully and keep this manual in a safe place for future reference

1. Installation

- 1. In order to secure the safe installation of the light, always use it in the well-ventilated environment.
- 2. Always keep this light with a safe distance from any flammable materials.
- 3. Never install, dismantle and maintain this light when it is powered; and all work aforesaid must be conducted by professionals.
- 4. The packing list of this light is as follows:
- 1) Light -----1pcs
- 2) Power Cable-----1pcs
- 3) User Manual-----1pcs

2. Effect

- 1. This light operation is very simple, Attractive appearance, Humanized design, Dim without flicker and shake, Energy-efficient, Durable. It is suitable for photography, television stations, stage, dance hall, KTV, bar, evening show.
- 2. The program of this light can automatically operate, sound, accept DMX512 signal control and be connected for use.

3. Menu display function table

Please press "Menu" button to choose function, and press "Enter" button to confirm.

Menu	Value	Function
d001	001-512	press "UP" and "Down" button change the
		DMX address
CH01	CH03	3CH model
	CH07	7CH model
Auxx	01	White color
	02	Color fade
	So01	Sound change by jumping
	So02	Sound change by strobe
St00	St01-St16	Strobe from slow to fast

CDOO	SP01-SP16	The speed of Auto model from slow to fast
SP00	SP01-SP16	for Au08 Au09 Au10 model
Sn00	Sn01-Sn16	Sound sensitivity form slow to fast
W000	000-255	White dimmer by dimming by hand
H000	000-255	Motor movement
RES		Confirm to reset

4. Technical Parameters

Voltage: AC100-240V, 50Hz/60Hz

Power Consumption: 200W

LED: 200W white Citizen COB LED

Beam Angle: 10-90°

LED Lifetime: 80,000-100,000 hours

Color:White color

Dimming: 0-100% with regulated constant color control

Strobe: 10 Flashes per second (any color)

Operation Modes: DMX512, Manual, Sound, Internal Program

DMX Control: 3/7 Channels

Control Panel: Digital 4 Character Alphanumeric

Maximum Ambient Temperature: 40° C

Gross Weight: 6.2 kg

Package Size: 32 x 32 x 39cm

5. DMX function

3CH model

Channel	Value	Function	
CH1	0-255	Zoom function	
CH2	0-255	Main dimming from dark to bright	
CH3	0-10	No function	
	11-20	Linear 1	
	21-30	Linear 2	
	31-40	Linear 3	
	41-249	Linear 4	
	250-255	Reset	